



OUTDOOR BOTTLE FILLER ANCHOR ASSY.

Accessory

The Anchor Assembly is the necessary accessory to secure your Oasis Outdoor Bottle Filler.

Designed for durability, it provides a stable and secure foundation by fastening the unit to the ground. Whether in parks, schools, or public spaces, this assembly ensures your bottle filler stays firmly in place.

Easy to install and built to last, it's the perfect solution for long-term outdoor installations.

Product Includes:

Adapter panel, rods and installation hardware




OUTDOOR BOTTLE FILER ANCHOR ASSY	
FINISH	Evergreen, White and Blue
DIMENSIONS	14" x 14" x 14-1/4"
Shipping Weight	36 lbs.



Safely Secures the OASIS Outdoor Bottle Filler to your Ideal location

SIDE VIEW



TOP + FRONT VIEW

